


1J1002 4 to 2 BNC Converter



The 1J1001 4 to 1 BNC Converter is used to connect a Wayne Kerr 6500 analyzer to the Device Under Test which is terminated in two BNC connectors.

The outers of the two BNC's should be joined together at the DUT.

Suitable models

6500B series Precision Impedance Analyzer 6500P series HF LCR Meter

Specification

Frequency: Connection to Analyzer: Connection to DUT: Transfer Standards: 20 Hz to 120 MHz 4-BNC 1 metre cable Two 8cm coaxial cables, each terminated with a male BNC 5-654-7014 Transfer Standard Box (supplied as standard) Containing Open, Short, 10 pF, 100 pF and 100Ω standards

UK GLOBAL HQ Wayne Kerr Electronics Ltd. Unit 1A, Durban Road, Bognor Regis, West Sussex, PO22 9QT

www.waynekerrtest.com